


# Emergency SOP



If a concealed material is identified during a repair/renovation, all work must stop, and a qualified consultant must be retained to perform testing before work can resume

# Abatement and Air Monitoring

